



# Braun Aromaster KF440 Filter Basket Replacement Guide

This guide breaks down the steps to removing the filter basket in order to replace it.

Written By: Darcy Groom



## INTRODUCTION

Removing the filter basket may be necessary if the filter basket is broken or clogged.

---



### TOOLS:

- [iFixit Opening Tools](#) (1)
-

## Step 1 — Remove the carafe.



- Remove the carafe from the coffee maker.
- Set the carafe aside.

## Step 2 — Open the filter basket.




- Grab the ridge on the left side of the coffee maker.
- Rotate the filter basket to the right.

### Step 3 — Remove the filter basket housing.



- Grab the filter basket firmly and lift upwards. You may need to use one hand to hold the body of the coffee maker in place in order to remove the piece.

### Step 4 — Loosen the filter basket from its housing.



- Wedge the plastic opening tool between the filter basket and its housing.
- Be sure to wedge the tools close to the tab on the right side of the housing.
- Wiggle tools to loosen the housing from the filter basket.



## Step 5 — Remove the filter basket from its housing.



- Once the filter basket has been pried loose, grab the filter basket and lift it out of the housing.

---

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 04:05:45 PM.